



Joplin as a bridge between a digital source and a computer lacking a digital audio input



Connect your digital source's coaxial output to the Joplin's coaxial digital input.



Set Joplin's input to "coax".



Connect the USB port of the Joplin to one of your computer's USB ports. Set Joplin as the preferred audio input device. Launch an audio acquisition application and begin acquiring your digital music on your computer.